


## Mutar<sup>®</sup> III 1.4x T\*



CONTAX<sup>®</sup>/YASHICA<sup>®</sup> mount

The Carl Zeiss **Mutar<sup>®</sup> III 1.4x T\*** teleconverter for the Carl Zeiss lens range for **Contax<sup>®</sup>** SLR cameras is inserted between the lens and the camera, increasing the focal length by a factor of 1.4. This reduces the aperture set on the lens by one f-stop. The exposure time is doubled accordingly.

This addition to the Mutar<sup>®</sup> I and II 2x teleconverters provides the Contax photographer with another possibility of extending his range of Carl Zeiss lenses, while obtaining very good image quality at the same time.

---

**Cat. No. of lens:**

Number of elements:

Number of groups:

Relative aperture:

Increase in focal length:

Negative format:

Mount:

position.

Spectral range:

Focusing range:

Distance between first and last lens vertex:

Weight:

**10 43 40**

6

4

Reduction of lens aperture set by 1 f-stop

1.4x

24 x 36 mm

Bayonet mount, TTL metering at full aperture or in stopped-down

Visible spectrum.

No major changes. See lens used.

29 mm

approx. 244 g

---

**ZEISS**

Combination possibilities:  
**Mutar**<sup>®</sup> III 1.4x T\* with Carl Zeiss T\* Lenses

Lens	Cat. No.	Edge brightness	Sharpness	Distortion
Planar <sup>®</sup> T* 2/100	102158	good	good	low
Planar <sup>®</sup> T* 2/135	101046	good	medium	low
Sonnar <sup>®</sup> T* 2.8/135	101083	good	good	low
Sonnar <sup>®</sup> T* 2.8/180	101117	good	good	low
Tele-Tessar <sup>®</sup> T* 4/200	104537	good	good	low
Aposonnar <sup>®</sup> T* 2.0/200	104548	good	good	low
Tele-Apotessar <sup>®</sup> T* 2.8/300	104533	good	good	low
Tele-Tessar <sup>®</sup> T* 4/300	104531	good	good	low
Vario-Sonnar <sup>®</sup> T* 4/80-200	104735	good	good	low
Mirotar <sup>®</sup> 4.5/500	104602	good	good	low

The camera lenses listed can be used with the **Mutar** III 1.4x T\* teleconverter. Their excellent image quality, good edge brightness and low distortion are not impaired by combining them with the **Mutar** III 1.4x T\* teleconverter.

For mechanical reasons, all Carl Zeiss lenses included in the range for **Contax** SLR cameras and not listed here cannot be combined with the **Mutar** III 1.4x T\* teleconverter.



**Carl Zeiss**  
Photoobjektive  
D-73446 Oberkochen  
Telephone (07364) 20-6175  
Fax (07364) 20-4045  
eMail: [photo@zeiss.de](mailto:photo@zeiss.de)  
<http://www.zeiss.de>

Subject to change.